




Sony BDP-BX620 Cover Removal

This guide presents all the necessary steps to remove and replace the Disk Drive from the Sony BDP-BX620.

Written By: Axel Cruz Jimenez







TOOLS:

- [Phillips #0 Screwdriver](#) (1)
-


Step 1 — Outer Cover




- Power on the device, eject the disk tray, and power off the device.
- Turn the device over.
- Lightly apply downward pressure on the black covering on the disk tray until it snaps off.

⚠ Caution, applying too much pressure can break the black covering.


Step 2



- Turn the device around.
 - Using a Phillips screw driver, remove the screws on both ends of the device circled red in the image.
 - Slide the side covers on either side towards the back of the device.
-  There is a back cover on either side of the device.


Step 3



 This step might require someone to help unclasping the plastic clips.

- Turn the device so that the bottom is facing up.
- In the bottom, unclip the three plastic clips circled in red.
- On either side, unclip the plastic clip circled in red
- Slide the black covering forwards to remove.

 All five clips have to be unclaspd for the covering to be removed.

 Careful not to break the plastic clips when putting it back on.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-22 03:21:59 PM.